



ES-ELECTRIC Line

Electronic surgical sink



STERILIZATION



Description

Aseptic surgical scrub sink molded in one piece without any join or sealing. With no overflow hole in order to avoid bacterial development, the sink has a large wall and sides protections against splashing water.

Available with a full range of accessories for an ideal configuration matching your specific need. Our team advises every customer according to the country's water quality and environment.

Material: Made of reinforced molded polyester resin fiberglass. The outer coating is made of high grade iso NPG sanitary gelcoat.

Targeted services: Operating rooms, emergency boxes, intensive care unit, dental surgery offices, cosmetic and plastic surgery offices, nephrology and dialysis units, critical care, neonatal unit.

Basic equipment

- 1/2/3 IR cells (according on the model) triggered by presence detection
- 220V AC device and battery device. Supplied 2 in 1
- System equipped with automatic flush (6h/12h/Off after last use)
- Easy setting with an optional remote control
- Control box easy to unclip for maintenance
- 1/2/3 Gooseneck taps (according on the model), chromed finish
- 1 Siphon of Ø40mm
- Regulation valve
- HDPE flexible connecting hoses
- Stainless steel fixing frame

Optional accessories

- Thermostatic mixer with anti-burn security
- Prefiltering kit 1 or 5µ with pressure protection system
- Autoclavable quick connected faucet
- Ultraviolet kit 40W
- Medical disinfectable glass siphon or dry siphon
- Terminal filter 0.2µ all germs, 14 or 31 days
- Terminal filter 0.2µ anti-legionella only 62 days
- Terminal filter 0.2µ autoclavable 60 cycles
- Terminal filter 0.2µ all germs 70 days
- Aluminum rail for accessories with PVC clipping frames
- Elbow command Airless Soap dispenser
- Electronic command Airless Soap dispenser
- Nail brush, paper dispenser
- Basket for accessories



ES-UNO/E

CODE

- ES-UNO/E**
- ES-DUO/E**
- ES-TRIO/E**

Dimensions

- L : 900 mm H : 745 mm D : 570 mm Weight : 15 Kg
- L : 1500 mm H : 745 mm D : 570 mm Weight : 19 Kg
- L : 2000 mm H : 745 mm D : 570 mm Weight : 27 Kg



ES-DUO/E



ES-TRIO/E



ESSE3 srl, Via Garibaldi 30
 14022 Castelnuovo D.B. (AT)
 Tel +39 011 99 27 706
 Fax +39 011 99 27 506
 e-mail: danielec@esse3-medical.com
 web: www.esse3-medical.com

